

Restore Factory Default Settings Guide

NF18ACV FAQs

This guide has been revised to include the latest changes and updates from the NF18ACV's new NC2 web user interface.

About Factory Resets



A factory reset on the NF18ACV returns all settings to the default settings as they were when shipped from the factory.



Important – It is particularly important to perform a factory reset after upgrading the NF18ACV firmware to ensure the firmware installation is completed correctly.

Factory Reset Methods

There are two methods that can be used to perform a successful factory reset:


-  Use the NF18ACV's graphical user interface (GUI) to complete a factory reset.
-  Manually perform a factory reset using the reset pinhole at the back of the NF18ACV.

This guide will explain both methods to complete a successful factory reset.

Web Interface Factory Reset

Log in to the Web Interface


- 1 Open a web browser (such as Internet Explorer, Google Chrome or Firefox), type <http://192.168.20.1> into the address bar and press **Enter**.
- 2 At the login screen, type **admin** into both the **User Name** and the **Password** fields and click the **Login>** button.



Login screen


Restore Default Settings from Web interface

- 1 Click on the **Advanced** menu on the left hand side of the screen, then click on the **Configurations** option in the **System** group.



Tools – Navigate to Advanced Configurations


- To reset the NF18ACV to its factory settings, select the **Factory Reset** radio button and click the **Restore Default Settings** button.



Restore Default Settings

 **Note** – You may also perform configuration Backup and restore configuration from this page.

- A pop-up dialog box will prompt: "Are you sure you want to restore factory default settings?"




Reset command confirmation dialog

- Click **OK** to confirm the reset.
- The NF18ACV will reboot.
- After the NF18ACV has rebooted you will need to log in to the NF18ACV and re-enter your broadband connection settings such as your **ADSL/VDSL User ID** and **Password**, etc. Please use the **Quick Start Guide** to set up your router.

Manual Factory Reset

- 1 Ensure the NF18ACV is powered on.
- 2 On the back side of the NF18ACV, there is a small hole in the plastic with the word "Reset" printed above it.

This is the recessed reset button:




Back panel of NF18ACV showing Reset pinhole

- 3 Insert the end of a paper-clip or other rigid, thin piece of metal into the **Reset** pinhole and depress and hold in for 10-12 seconds.

If this does not happen:

- a Disconnect the power supply cable for 30 seconds and then reconnect it.
 - b Then depress the **Reset** button and hold in for 10-12 seconds.
- 4 The NF18ACV is back to its factory defaults, you now need to reconfigure the broadband settings via the user interface.

 **Note** – If you had previously backed up your configuration, you can now restore your settings by uploading your **.config** file.

- 5 To reconfigure the broadband settings :
 - a Open a web browser (such as Internet Explorer, Google Chrome or Firefox), type <http://192.168.20.1> into the address bar and press **Enter**.
 - b At the login screen, type **admin** into both the **User Name** and the **Password** fields and click **OK** or **Log In**.