BACKUP & RESTORE SETUP GUIDE

NF20MESH FAQs







Backup your settings

This guide provides you with instructions to back up and restore your router configuration. It is recommended to make a backup of the current working configuration in case you lose your settings or need to perform a factory reset (i.e. reset default settings).

- 1. Connect a computer and NF20MESH using an Ethernet cable. (A yellow Ethernet cable is provided with your **NF20MESH**).
- 2. Open a web browser using a PC or Laptop (such as Internet Explorer, Google Chrome or Firefox), type following address into the address bar and press enter.

http://192.168.20.1


Type" **admin**" in the **Username** and password printed on the back of the modem in the Password field and click the **Login** button.

NOTE – Some Internet Service Providers use custom password. If login fails, contact your Internet Service Provider. Use your own password if it is changed.




3. From the Advanced menu, Under System click on Configurations.





4. From the Settings page Select the **Backup** radio button and Click on **Backup Settings** Button.





5. A file named "backupsettings.conf" will be downloaded to your Download directory. Move that file to any of your preferred directory to keep it safe.


Note: - The backup file can be renamed to something meaningful to you but its file extension (.config) must be retained.

Restore your settings

This section provides you with instructions to restore the saved configuration.

- 1. From the Advanced menu, Click on Configurations in the System group. The Setting page will open.
- 2. From the **Settings** page Select the **Update** radio button and Click on the **Choose file** button to open the file selector dialog.





- 3. Locate the **Backup Settings** file that you want to restore.
- 4. Click to select the file, its file name will appear to the right of the **Choose file** button on the **Setting** page.
- 5. If you are satisfied that the file is the correct backup, click on the **Update Settings** button to reinstall your previously saved configuration settings.

Note - The NF20MESH will update the settings and restart. The process will take around 1-2 minutes.