

Change Administration Password Guide

NF18ACV FAQs

Password Overview

Changing the default password allows you to prevent unauthorized access to the administration page of your NF18ACV.

You can change both the default password and the default username.

Remember your username and password

Once the username and password have been changed, you must remember the words or strings of characters that you have defined.

If you forget your administration page login details, you will need to perform a factory reset to restore the default username and password of admin, see below. The major drawback of a factory reset is that it will also clear any stored settings on your NF18ACV. If you have made custom settings and have neglected to back up your settings, you will have to re-enter all of them into the NF18ACV.



Important – NetComm Technical Support does not have a record of your personal username and/or password.




Change the default password

This guide will take you through the process of changing the password required to login to the Administration page of your NF18ACV.

Initial log in to the Web interface of the NF18ACVC

Open a web browser (such as Internet Explorer, Google Chrome or Firefox), type http://192.168.20.1 into the address bar and press Enter.




2 At the login screen, type admin into both the User Name and the Password fields and click OK.



Customise the username and password

- 1 From the **Management** menu on the left, select **Access Control** and then **Passwords** from its sub-menu.
- 2 The Access Control Passwords screen will open:



- 3 Enter "admin" as the Username.
- 4 Enter your new user name into the **New Username** field.
- 5 Enter the current password into the **Old Password** field (initially this will be "admin").
- 6 Enter a new password into the **New Password** field.
- 7 Enter the new password once again into the **Confirm Password** field.
- 8 Click the **Apply/Save** button.



Important – Remember your personal user name and password.

If you forget it, you will have to factory reset and reset or restore all of your internet settings.

NF18ACV FAQs 3 of 3