



# Changing the Default Administration Password

## Modem Router - **NF4V**



# Changing the Default Administration Password

Changing the **default** password allows you to prevent unauthorized access to the administration page of your router.



Technical Support are unable to obtain your username and password.

If you forget your administration page login details, you will need to perform a factory reset to restore the default username and password of **admin**.

This will also clear any stored settings on your modem / router / VOIP ATA.

# Changing the default password


This guide will take you through the process of changing the password required to login to the administration page of your modem / router / VOIP ATA.

## LOGGING IN TO THE WEB INTERFACE

1. Open a web browser (such as Internet Explorer, Google Chrome or Firefox), type **http://192.168.20.1** into the address bar and press **enter**.
2. At the login screen, type **admin** into both the Username and the Password fields and click **OK**.



3. Click on the **Management** menu on the left hand side menu of the page and then click on **Access Control** option



4. Enter **"admin"** as the username
5. Enter your new username into the **New/Username** field.
6. Enter the old password into the **Old Password** field.
7. Enter a new password into the **New Password** field.
8. Enter The new password once again into the **Confirm Password** field.
9. Press the **Apply/Save** button.

You will then be prompted to re-login to the administration page.

Remember to use the new password (and username if you changed it) you have just entered.