

USB STORAGE SETUP GUIDE

NF20MESH FAQs



Storage Service

The Storage Service options enable you to manage attached USB Storage devices and create accounts to access the data stored on the attached USB device.

Storage Device Info

The storage device info page displays information about the attached USB Storage device.


Log in to the web interface

1. Open a web browser (such as Internet Explorer, Google Chrome or Firefox), type following address into the address bar and press enter.


<http://192.168.20.1>

Type “**admin**” in the Username and password printed on the back of the modem in the Password field and click the **Login** button.

NOTE – Some Internet Service Providers use custom password. If login fails, contact your Internet Service Provider. Use your own password if it is changed.




- Click on the **Content Sharing** menu at the left of the page.




- ☒ Enable **Samba (SMB) Share** and provide user account details.

Click the **Apply/Save** button to create a user account.




4. Adding an account allows the creation of specific user accounts with a password to further control access permissions.



Accessing USB hard drive Connected to NF20MESH using a Windows PC

5. Exit out from the NetComm router's WEB Interface page and open the "Windows Explorer" and type \\192.168.20.1 on the top address bar.



NOTE – Windows Explorer is different from the Internet Explorer. You can open a Windows Explorer by opening Computer or Documents.




IMPORTANT – Turn off firewall/ antivirus firewall if it has no connection to USB storage through Wireless.

6. When prompted for login details, type the Storage User Account **Username** and **Password**. The example below uses “**user1**” as the username.




7. Once you have **logged in**, you will be able to **view and edit** the contents of the USB storage device.




Accessing USB hard drive Connected to NF20MESH using a Mac PC


1. On you Mac click on **Go > Connect to a Server**.



2. Enter the path to the network drive you want to map, ie: **smb://192.168.20.1** then click **Connect**.



3. Enter your Storage User Account **Username** and **Password** as shown below and click the **Connect** button to mount the network drive.



4. The drive will now appear on your **finder window sidebar**.

