

**NetComm**<sup>®</sup>  
*www.netcomm.com.au*

 **Dynalink**

---

## **Changing the default administration password**

(NB6PLUS4)

## **Changing the default administration page password**

Changing the default password (and username)\* allows you to prevent unauthorised access to the administration page of your modem / router / VOIP ATA.



Technical Support are unable to obtain your username and password.

If you forget your administration page login details, you will need to perform a factory reset to restore the default username and password of **admin**.

This will also clear any stored settings on your modem / router / VOIP ATA.

\* - If supported by your model of modem / router.

## Changing the default password

This guide will take you through the process of changing the password required to login to the administration page of your modem / router / VOIP ATA.

1. Open your web browser and go to the address <http://192.168.1.1>, using **admin** as the username and password.
2. Click on "**Management**" from the menu at the top of the page.
3. Click on "**Management Accounts**" from the menu on the lefthandside of the page.
4. Enter the password you would like to use into the "**New Password:**" and "**Confirm New Password:**" sections

(if you would also like to change the username, replace "**admin**" with your chosen username)

The screenshot shows the NetComm router administration interface. At the top, there is a navigation bar with the NetComm logo and menu items: Quick Start, Status, Advanced, and Management. A language dropdown menu is set to English. On the left, a sidebar menu includes: Diagnostics, Management Accounts (highlighted), Management Control, Internet Time, System Log, Backup Config, Update Firmware, and Reset Router. At the bottom left of the sidebar, it displays 'Firmware: 3.64y' and 'ADSL2+ : A2pB025c.d20h'. The main content area is divided into two sections: 'Admin Account' and 'User Account'. The 'Admin Account' section has a description: 'Admin account has unrestricted access to change and view configuration of your DSL router.' It contains three input fields: 'User Name' (pre-filled with 'admin'), 'New Password', and 'Confirm New Password'. The 'New Password' and 'Confirm New Password' fields are highlighted with a red border. Below these fields are 'Apply' and 'Cancel' buttons. The 'User Account' section has a description: 'Using the user account can configure most common functions and view statistics of your DSL router.' It also contains three input fields: 'User Name' (pre-filled with 'user'), 'New Password', and 'Confirm New Password', followed by 'Apply' and 'Cancel' buttons.

5. Click "**Apply**".

You will then be prompted to re-login to the administration page. Remember to use the new password (and username if you changed it) you have just entered.